

Lista podržanih uređaja za MOVE 3

- 1. Apple uređaji od iOS15**
- 2. Android mobile od ATV7**
- 3. Samsung Tizen od 2018 Tizen 4.0**
- 4. ATV – od androida 8**
- 5. LG – od webOS 4.0**
- 6. Hisense VIDA OS – slijedi info**
- 7. Amazon Firestick – slijedi info**

